



Test procedures

BETA CAP

Symptoms	Test procedure	Probable cause and fix
Heat press going over set temperature		1. Faulty thermo couple 2. Faulty controller
Timer does not activate (start counting down)	Pressure lever in down position	1. Faulty connection/ loose on controller or micro switch 2. Faulty micro switch
Timer does not reset (buzzer does not stop)	Lever in up position	1. Micro switch needs adjusting 2. Faulty micro switch
Heat fault on digital display		1. Faulty controller 2. Open circuit on element
Probe fault on digital display		1. Loose connection on controller connector block (probe) 2. Faulty probe (thermo couple)
CAL fault on digital display		1. Controller needs recalibrating
Heat plate not heating	Digital display not illuminating	1. Check power supply and fuse 2. Faulty fuse holder/ switch 3. Faulty wiring or connector 4. Faulty controller
	Open circuit on element	1. Faulty thermal cut-out 2. Faulty wiring or connector 3. Faulty heat element
Pressure low when Press is operated	When lever is moved down	1. Handwheel needs adjusting
When Pressing Lever is raised to the up position it keeps falling down		1. Broken or damaged arm springs